



Weather Pack Assembly Instructions



Step 1

Install terminal seal and strip wire 3/16".



Step 2

Position the terminal. You may squeeze the insulation crimp lightly with your fingers to maintain position during crimping.



Step 3

Crimp the terminal.



Step 4

Just snap the terminal into the connector body and you're done. If you ever need to remove a terminal from a connector body, use Pico # 200-31 which includes an extractor tool, a narrow pick .05" and a wide pick .09".