


## Ignition Switch



### Ignition Switch

Plated Steel. Includes 2 keys.  
3/4" Mount Hole  
12V @ 30A

Part No.	Qty
9448-BP	1

## Dual Battery Selector



### Marine I & II Dual Battery Selector Switch

Master battery selector and disconnect switch for application up to 36VDC, 4 positions-both/1/off/2. Rating: 310 Amps Continuous 500Amps/5 mins.

Part No.	Qty
9455-31	1



### Mini Dual Marine Battery Switch

100A continuous, 1000A cranking

Part No.	Qty
9457-11	1

## Master Battery Disconnect Switch



### Mini Battery Switch Rotary Release

32V DC Max.  
Two position SPST  
OFF-ON

Part No.	Amps	Qty
9420-11	200	1
9421-11	300	1



### Master Battery Disconnect Switch

Single circuit battery master switch provides anti-theft and fire protection. Detachable key for anti-theft. Includes weather resistant cap. Ideal for RV, marine and farm equipment. 12V DC 350A Continuous, 500A Momentary

Part No.	Qty	Description
9450-11	1	
9450-34	10	
9480-11	1	9450 Spare Key



### 12 & 24 V DC Battery Disconnect Switch

Battery disconnect switch with fixed handle. 12V 500 Amps, 24V 250Amps, 2000Amps/5 secs Momentary IP65

Part No.	Qty
9456-31	1
9456-34	10



### UL 588 Heavy Duty Master Battery Disconnect

Disconnects battery circuit only. Does not disconnect alternator or generator field circuit. When used on alternator equipped vehicles, the engine should be stopped before switching to the OFF position to prevent possible alternator diode failure. 6-36V DC, 3/4" Mount Hole 190A Continuous, 1000A Momentary

Part No.	Qty
9449-11	1
9449-34	10



### Metal Lock Out Bracket for 9456



Part No.	Qty
9458-31	1
9458-34	10



### IP 67 Master Battery Disconnect Switch

300 Amps 12V DC Max  
Two position SPST  
OFF-ON

Part No.	Qty
9481-11	1

